



Akumulator HR1234WF2

CSB 9,0Ah 12,0V HR1234

Żywotność technologiczna akumulatora HR1234 3-5 lat

HR 1234WF2 CSB 9,0Ah 12,0V 9 Ah w obudowie 7,2 Ah /GP/ Gwarancja 24 miesiące	info	typ	Napięcie	Pojemność
	akumulator dedykowany do pracy buforowej	AGM	wysoko prądowy	12,0V 9,0Ah

Zastępuje akumulatory o nr / typ / cecha :

APC:

APC RBC12 (8 szt akumulatorów) , **APC** RBC17 (1 szt akumulatorów) , **APC** RBC2 (1 szt akumulatorów) , **APC** RBC22 (2 szt akumulatorów) , **APC** RBC23 (4 szt akumulatorów) , **APC** RBC24 (4 szt akumulatorów) , **APC** RBC25 (4 szt akumulatorów) , **APC** RBC26 (8 szt akumulatorów) , **APC** RBC27 (8 szt akumulatorów) , **APC** RBC31 (4 szt akumulatorów) , **APC** RBC32 (2 szt akumulatorów) , **APC** RBC33 (2 szt akumulatorów) , **APC** RBC36 (8 szt akumulatorów) , **APC** RBC37 (8 szt akumulatorów) , **APC** RBC40 (1 szt akumulatorów) , **APC** RBC48 (2 szt akumulatorów) , **APC** RBC51 (1 szt akumulatorów) , **APC** RBC5 (2 szt akumulatorów) , **APC** RBC53 (3 szt akumulatorów) , **APC** RBC54 (4 szt akumulatorów) , **APC** RBC59 (4 szt akumulatorów) , **APC** RBC60 (2 szt akumulatorów) , **APC** RBC62 (2 szt akumulatorów) , **APC** RBC8 (4 szt akumulatorów) , **APC** RBC9 (2 szt akumulatorów)

Yuasa:

NP7-12; Y7-12 ;

Powersonic:

PS-1265; PS-1270; PS-1270F2;

Panasonic:

LC-R127R2P; LC-R127R2P1; LC-R127R2PG1; LCR12V6.5BP; LCP126R5P; LCR12V7.2P;

CSB:

GH1270; GP1270; GP1272; GP-1272; GP 1272; HR1270; B&B BP7-12 BP7.2-12;

Ritar:

RT 1275; RT1275;

Rocket:

ES7-12;

Sonnenschein:

A506/6.5S; A512/6.5S; GS Portalac PE12V7 PE12V9F2 PX12090 PWL12V7; Hitachi HP7-12; Exide EP7-12; Ultracell CB7-12; Injusa IJ7-12; Diamec DM12-7.2;

Stosowany w UPS-ach:

APC:

BK250EC, BK250EI, BP280I, BK400i, BK400EC, BK400EI, BP420I, SUVS420i, BK500MI, BK500I, BK350EI, BK500EI; SmartUPS VS420; Smart-UPS 450; Smart-UPS 600; Smart-UPS 700; Smart-UPS 750; Smart-UPS SU1400RM2U (4 szt); Smart-UPS SU1000RM2U (4 szt);

Ever:

ECO PRO 500; ECO 500; ECO 700 CDS; ECO Pro 700 CDS;

Fideltronik:

Ares 1000; Ares 1600; Ares 3000; Ares 500; Ares 700; Ares Cool; Ares LT1; Ares LT2; Ares LT3; LUPUS 1000; LUPUS 1500; LUPUS 1600; LUPUS 500; LUPUS 700; LUPUS KI 1000; LUPUS KI 2000; LUPUS KI 3000; LUPUS KR1000; LUPUS KR2000; LUPUS KR2000-J; LUPUS KR3000; LUPUS KR3000-J; MB4814; MB4821;

ORVALDI:

1052F; 1062F; BL600; JP, JPXL;

Akumulator występuje w UPS-ach:

APC 330XT (2 Batteries Required) , **APC** 360SX (2 Batteries Required) , **APC** 600 (2 Batteries Required) , **APC** 600R (2 Batteries Required) , **APC** 600RM (2 Batteries Required) , **APC** AP280 (1

Battery Required) , **APC** AP330 (1 Battery Required) , **APC** AP330XT (1 Battery Required) , **APC** AP360 (1 Battery Required) , **APC** AP360SX (1 Battery Required) , **APC** AP600 (2 Batteries Required) , **APC** AP600RM (2 Batteries Required) , **APC** APC400 (2 Batteries Required) , **APC** APC420 (2 Batteries Required) , **APC** BACK-UPS 1200VA (BR1200) (2 Batteries Required) , **APC** BACK-UPS 2200 (2 Batteries Required) , **APC** BACK-UPS 250VA Intl (BK250i) (1 Battery Required) , **APC** BACK-UPS 300 (1 Battery Required) , **APC** BACK-UPS 300 (BK300C) (1 Battery Required) , **APC** BACK-UPS 300 w/L5-15 (BK300X116) (1 Battery Required) , **APC** BACK-UPS 400 (1 Battery Required) , **APC** BACK-UPS 400B (1 Battery Required) , **APC** BACK-UPS 500 (1 Battery Required) , **APC** BACK-UPS 500 (BK500MC) (1 Battery Required) , **APC** BACK-UPS 500U (1 Battery Required) , **APC** BACK-UPS 500VA Industrial Din Rail UPS (SP500DR) (1 Battery Required) , **APC** BACK-UPS 900VA (BR900) (2 Batteries Required) , **APC** BACK-UPS BK200 (1 Battery Required) , **APC** BACK-UPS BK200C (1 Battery Required) , **APC** BACK-UPS BK250B (1 Battery Required) , **APC** BACK-UPS BK280B (1 Battery Required) , **APC** BACK-UPS BK300 (1 Battery Required) , **APC** BACK-UPS BK300C (1 Battery Required) , **APC** BACK-UPS BK300X116 (1 Battery Required) , **APC** BACK-UPS BK300XII (1 Battery Required) , **APC** BACK-UPS BK350 (1 Battery Required) , **APC** BACK-UPS BK350EI (1 Battery Required) , **APC** BACK-UPS BK400 (1 Battery Required) , **APC** BACK-UPS BK400B (1 Battery Required) , **APC** BACK-UPS BK500 (1 Battery Required) , **APC** BACK-UPS BK500M (1 Battery Required) , **APC** BACK-UPS BK500MC (1 Battery Required) , **APC** BACK-UPS BP280 (1 Battery Required) , **APC** BACK-UPS BP280B (1 Battery Required) , **APC** BACK-UPS BP350 (1 Battery Required) , **APC** BACK-UPS BP420 (1 Battery Required) , **APC** BACK-UPS BP420S (1 Battery Required) , **APC** BACK-UPS BP500 (all) (1 Battery Required) , **APC** BACK-UPS BP500CLR (1 Battery Required) , **APC** BACK-UPS BP500LS (1 Battery Required) , **APC** BACK-UPS BP500UC (1 Battery Required) , **APC** BACK-UPS BP600 (1 Battery Required) , **APC** BACK-UPS BP700LS (1 Battery Required) , **APC** BACK-UPS BR1000I (2 Batteries Required) , **APC** BACK-UPS BR1000-IN (2 Batteries Required) , **APC** BACK-UPS BR1500I (2 Batteries Required) , **APC** BACK-UPS BR1500-IN (2 Batteries Required) , **APC** BACK-UPS BX1000 (2 Batteries Required) , **APC** BACK-UPS BX1500 (2 Batteries Required) , **APC** BACK-UPS CS 350VA (BK350) (1 Battery Required) , **APC** BACK-UPS CS 500 (BK500) (1 Battery Required) , **APC** BACK-UPS CS 500 Black (BK500BLK) (1 Battery Required) , **APC** BACK-UPS CS BK350 (1 Battery Required) , **APC** BACK-UPS CS BK350E1 (1 Battery Required) , **APC** BACK-UPS CS BK500 (1 Battery Required) , **APC** BACK-UPS CS BK500E1 (1 Battery Required) , **APC** BACK-UPS ES 500 (BE500U) (1 Battery Required) , **APC** BACK-UPS ES500VA (BE500C) (1 Battery Required) , **APC** BACK-UPS ES 650VA USB (BR650BB) (4 Batteries Required) , **APC** BACK-UPS ES 725VA Broadband (BE725BB) (4 Batteries Required) , **APC** BACK-UPS LS500 (BP500UC) (1 Battery Required) , **APC** BACK-UPS LS500 Clear (BP500CLR) (1 Battery Required) , **APC** BACK-UPS LS 700 (BP700UC) (4 Batteries Required) , **APC** BACK-UPS Powerstack 250 (1 Battery Required) , **APC** BACK-UPS PRO 280 (1 Battery Required) , **APC** BACK-UPS PRO 280 (BP280IPNP) (1 Battery Required) , **APC** BACK-UPS PRO 280BPNP (1 Battery Required) , **APC** BACK-UPS PRO 280C (1 Battery Required) , **APC** BACK-UPS PRO 280PNP (1 Battery Required) , **APC** BACK-UPS PRO 280PNP (BP280PNP) (1 Battery Required) , **APC** BACK-UPS PRO 280S (1 Battery Required) , **APC** BACK-UPS PRO 280VA (BP280S) (1 Battery Required) , **APC** BACK-UPS PRO 350U (1 Battery Required) , **APC** BACK-UPS PRO 350VA (1 Battery Required) , **APC** BACK-UPS PRO 420 (1 Battery Required) , **APC** BACK-UPS PRO 420 (BP420iPNP) (1 Battery Required) , **APC** BACK-UPS PRO 420C (1 Battery Required) , **APC** BACK-UPS PRO 420PNP (1 Battery Required) , **APC** BACK-UPS PRO 420S (1 Battery Required) , **APC** BACK-UPS PRO 420VA (BP420S) (1 Battery Required) , **APC** BACK-UPS PRO 500 (1 Battery Required) , **APC** BACK-UPS PRO 500CLR (1 Battery Required) , **APC** BACK-UPS PRO 500U (1 Battery Required) , **APC** BACK-UPS PRO 500VA (BP500U) (1 Battery Required) , **APC** BACK-UPS PRO BP280C (1 Battery Required) , **APC** BACK-UPS PRO BP280IPNP (1 Battery Required) , **APC** BACK-UPS PRO BP280PNP (1 Battery Required) , **APC** BACK-UPS PRO BP280S (1 Battery Required) , **APC** BACK-UPS PRO BP280SUS (1 Battery Required) , **APC** BACK-UPS PRO BP280SX116 (1 Battery Required) , **APC** BACK-UPS PRO BP420C (1 Battery Required) , **APC** BACK-UPS PRO BP420IPNP (1 Battery Required) , **APC** BACK-UPS PRO BP420PNP (1 Battery Required) , **APC** BACK-UPS PRO BP420S (1 Battery Required) , **APC** BACK-UPS PRO BP420SUS (1 Battery Required) , **APC** BACK-UPS PRO USB 350VA (BP350U) (1 Battery Required) , **APC** BACK-UPS PRO USB 350VA (BP350UC) (1 Battery Required) , **APC** BACK-UPS PRO USB BP350UC (1 Battery Required) , **APC** BACK-UPS PRO USB BP500CLR (1 Battery Required) , **APC** BACK-UPS PRO USB BP500UC (1 Battery Required) , **APC**

BACK-UPS PRO w/L5-15R (BP280SX116) (1 Battery Required) , **APC** BACK-UPS RS1000 (2 Batteries Required) , **APC** BACK-UPS RS1000VA (2 Batteries Required) , **APC** BACK-UPS RS1500 (2 Batteries Required) , **APC** BACK-UPS RS 1500VA (2 Batteries Required) , **APC** BACK-UPS RS 800VA Black (BR800BLK) (2 Batteries Required) , **APC** BACK-UPS RS 800VA (BR800) (2 Batteries Required) , **APC** BE500U (1 Battery Required) , **APC** CS350 (1 Battery Required) , **APC** GP1270F2 (2 Batteries Required) , **APC** LCR12V6.5 (2 Batteries Required) , **APC** PCPER (1 Battery Required) , **APC** PCPRO (1 Battery Required) , **APC** Personal Power Cell (2 Batteries Required) , **APC** POWERCELL PERSONAL POWERCELL (1 Battery Required) , **APC** POWERSHIELD CP15U48D (1 Battery Required) , **APC** POWERSHIELD CP24U12D (1 Battery Required) , **APC** POWERSHIELD CP36U52 (1 Battery Required) , **APC** PRO 250 (2 Batteries Required) , **APC** Professional Power Cell (2 Batteries Required) , **APC** RackMount 600 (2 Batteries Required) , **APC** RBK600 (2 Batteries Required) , **APC** RVC12 (2 Batteries Required) , **APC** SMART-UPS 1000 RACK EXTENDED (4 Batteries Required) , **APC** SMART-UPS 1000VA USB and SER (SUA1000RMUS) (4 Batteries Required) , **APC** SMART-UPS 1400RM2U (4 Batteries Required) , **APC** SMART-UPS 1400RM3U (SU1400RMNET) (4 Batteries Required) , **APC** SMART-UPS 1400RM (4 Batteries Required) , **APC** SMART-UPS 1400RM Black (SU1400RMBX120) (4 Batteries Required) , **APC** SMART-UPS 1400RMNET (4 Batteries Required) , **APC** SMART-UPS 1400RM (SU1400RM) (4 Batteries Required) , **APC** SMART-UPS 1400VARM2U (SU1400R2BX120) (4 Batteries Required) , **APC** SMART-UPS 1400VARM2U (SU1400R2X122) (4 Batteries Required) , **APC** SMART-UPS 1400VARM2U (SU1400RM2U) (4 Batteries Required) , **APC** SMART-UPS 1400VARM2U (SU1400RM2UX93) (4 Batteries Required) , **APC** SMART-UPS 1400VARM3U (SU1400RMX106) (4 Batteries Required) , **APC** SMART-UPS 1400VARM3U (SU1400RMX176) (4 Batteries Required) , **APC** SMART-UPS 1500VARM2U (SUA1500R2X122) (4 Batteries Required) , **APC** SMART-UPS 1500VARM2U (SUA1500R2X93) (4 Batteries Required) , **APC** SMART-UPS 1500VA USB and SER (SUA1500RM2U) (4 Batteries Required) , **APC** SMART-UPS 1500VA USB RM (DLA1500RM2U) (4 Batteries Required) , **APC** SMART-UPS 330 (AP330) (1 Battery Required) , **APC** SMART-UPS 330XT+ (AP330XT+) (1 Battery Required) , **APC** SMART-UPS 360 (AP360) (1 Battery Required) , **APC** SMART-UPS 360SX (1 Battery Required) , **APC** SMART-UPS 360SX (AP360SX) (1 Battery Required) , **APC** SMART-UPS 420 (1 Battery Required) , **APC** SMART-UPS 420VA (SU420NET) (1 Battery Required) , **APC** SMART-UPS 420VA (SUVS420) (1 Battery Required) , **APC** SMART-UPS 450 (2 Batteries Required) , **APC** SMART-UPS 450 NET (SU450NET) (2 Batteries Required) , **APC** SMART-UPS 450 (SU450) (2 Batteries Required) , **APC** SMART-UPS 600 (2 Batteries Required) , **APC** SMART-UPS 600 (AP600) (2 Batteries Required) , **APC** SMART-UPS 600LS (2 Batteries Required) , **APC** SMART-UPS 700 (2 Batteries Required) , **APC** SMART-UPS 700RM3U (SU700RM) (2 Batteries Required) , **APC** SMART-UPS 700VA Black (SU700BX120) (2 Batteries Required) , **APC** SMART-UPS 700VA (DL700) (2 Batteries Required) , **APC** SMART-UPS 700VA NAFTA (SU700US) (2 Batteries Required) , **APC** SMART-UPS 700VA RM2U (SU700R2BX120) (2 Batteries Required) , **APC** SMART-UPS 700VARM2U (SU700RM2U) (2 Batteries Required) , **APC** SMART-UPS 700VA RM3U (SU700RMNET) (2 Batteries Required) , **APC** SMART-UPS 700VA Ship (SU700X93) (2 Batteries Required) , **APC** SMART-UPS 700VA (SU700NET) (2 Batteries Required) , **APC** SMART-UPS 750VA USB and SER (SUA750RM2U) (2 Batteries Required) , **APC** , **APC** SMART-UPS RM SU1400RM (4 Batteries Required) , **APC** SMART-UPS RM SU1400RMBX120(34) (4 Batteries Required) , **APC** SMART-UPS RM SU1400RM NET (4 Batteries Required) , **APC** SMART-UPS RM SU1400RMX106 (4 Batteries Required) , **APC** SMART-UPS RM SU1400RMX176 (4 Batteries Required) , **APC** SMART-UPS RM SU1400RMX93 (4 Batteries Required) , **APC** SMART-UPS RM SU1500RMX155 (4 Batteries Required) , **APC** SMART-UPS RM SU1500RMXLX157 (4 Batteries Required) , **APC** SMART-UPS RM SU5000RMXLT5U (16 Batteries Required) , **APC** SMART-UPS RM SU700RM (2 Batteries Required) , **APC** SMART-UPS RM SU700RM NET (2 Batteries Required) , **APC** SMART-UPS SC 420VA (SC420) (1 Battery Required) , **APC** SMART-UPS SL1400VARM3U (SU1400RMXL3U) (4 Batteries Required) , **APC** SMART-UPS SMART 1000VARM2U (SU1000R2BX120) (4 Batteries Required) , **APC** SMART-UPS SMART 1000VARM2U (SU1000RM2U) (4 Batteries Required) , **APC** SMART-UPS SMART 1000VA USB and SER (SUA1000RM2U) (4 Batteries Required) , **APC** SMART-UPS SMART 1000XLI (4 Batteries Required) , **APC** SMART-UPS SMART SC1000VA (SC1000) (2 Batteries Required) , **APC** SMART-UPS SMART XL1000VA USB (SUA1000XL) (2 Batteries Required) , **APC** SMART-UPS SP500DR (1 Battery Required) , **APC** SMART-UPS SU1000RM2U (4 Batteries Required) , **APC** SMART-UPS SU1400RMNET (4 Batteries Required) , **APC** SMART-UPS

SU1400RM (RACK) (4 Batteries Required) , **APC** SMART-UPS SU1400RMXLIB3U (4 Batteries Required) , , **APC** SMART-UPS SU600 (2 Batteries Required) , **APC** SMART-UPS SU700 (2 Batteries Required) , **APC** SMART-UPS SU700BX120 (2 Batteries Required) , **APC** SMART-UPS SU700NET (2 Batteries Required) , **APC** SMART-UPS SU700RMNET (2 Batteries Required) , **APC** SMART-UPS SU700X167 (2 Batteries Required) , **APC** SMART-UPS SUA1000RMI2U (4 Batteries Required) , **APC** SMART-UPS SUA1500R2X138 (4 Batteries Required) , **APC** SMART-UPS SUO2000XLI (4 Batteries Required) , **APC** SMART-UPS SUOL1000XLI (4 Batteries Required) , **APC** SMART-UPS SURT2000RMXLI (4 Batteries Required) , **APC** SMART-UPS SURT2000XLI (4 Batteries Required) , **APC** SMART-UPS SUVS420 (1 Battery Required) , **APC** SMART-UPS XL1400VARM 3U (SU1400RMXLB3U) (4 Batteries Required) , **APC** UPS300 (2 Batteries Required) , **APC** UPS370CI (2 Batteries Required) , **APC** UpStart350 (2 Batteries Required) , **APC** UXBP48M (2 Batteries Required) , **ATandT** 515 (3 Batteries Required) , **Belkin** F6C120AU (2 Batteries Required) , **Belkin** F6C350-USB (1 Battery Required) , **Belkin** F6C425-SER (1 Battery Required) , **Belkin** F6C500USB (1 Battery Required) , **Belkin** F6C800-UNV (1 Battery Required) , **Belkin** F6H650 (1 Battery Required) , **Belkin** PRO F6C425 (1 Battery Required) , **Belkin** PRO F6C525 (1 Battery Required) , **Belkin** PRO F6C625 (1 Battery Required) , **Belkin** Pro F6C650 (1 Battery Required) , **Belkin** PRO F6C700 (2 Batteries Required) , **Belkin** Pro Gold F6C250-USB (1 Battery Required) , **Belkin** PRO GOLD F6C350-USB (1 Battery Required) , **Belkin** PRO GOLD F6C425-SER (1 Battery Required) , **Belkin** Pro Gold F6C500-USB (1 Battery Required) , **Belkin** Pro Net UPS F6C700 (2 Batteries Required) , **Best Power** 280 UPS (1 Battery Required) , **Best Power** 420 UPS (1 Battery Required) , **Best Power** BEST LI-660VA (2 Batteries Required) , **Best Power** FERRUPS Blackout Buster (1 Battery Required) , **Best Power** FORTRESS 1422 BTG-0303 (4 Batteries Required) , **Best Power** FORTRESS 750 BAT-0062 (2 Batteries Required) , **Best Power** Fortress II LI 1020 BTG-0302 (3 Batteries Required) , **Best Power** Fortress II LI 1420 BTG-0303 (4 Batteries Required) , **Best Power** Fortress II LI 520 BTG-0301 (2 Batteries Required) , **Best Power** Fortress II LI 720 BTG-0301 (2 Batteries Required) , **Best Power** FORTRESS LI 1050 (3 Batteries Required) , **Best Power** FORTRESS LI 1425 BAT-0062 (4 Batteries Required) , **Best Power** Fortress LI 520 BAT-0062 (2 Batteries Required) , **Best Power** Fortress LI 660 BAT-0062 (2 Batteries Required) , **Best Power** Fortress LI 675 BAT-0062 (2 Batteries Required) , **Best Power** Fortress LI 720 BAT-0062 (2 Batteries Required) , **Best Power** Fortress Rack Mount LI 720 BAT-0370 (2 Batteries Required) , **Best Power** PATRIOT 0305-0250U (1 Battery Required) , **Best Power** PATRIOT 0305-0425U (1 Battery Required) , **Best Power** PATRIOT 420 UPS (1 Battery Required) , **Best Power** PATRIOT Blackout Buster (1 Battery Required) , **Best Power** PATRIOT SMT280 (1 Battery Required) , **Best Power** PATRIOT SMT420 (1 Battery Required) , **Best Power** PATRIOT SPI1250 (1 Battery Required) , **Best Power** PATRIOT SPI1400 (1 Battery Required) , **Best Power** PATRIOT SPS450 (1 Battery Required) , **Best Power** PATRIOT SPS850 (2 Batteries Required) , **Best Technologies** BTG-0301 (2 Batteries Required) , **Best Technologies** BTG-0302 (3 Batteries Required) , **Best Technologies** BTG-0303 (4 Batteries Required) , **Best Technologies** Fortress 1050 (1 Battery Required) , **Best Technologies** Fortress 1425 (1 Battery Required) , **Best Technologies** Fortress II LI 660VA (8 Batteries Required) , **Best Technologies** Fortress LI 1420 (BTG-0303) (4 Batteries Required) , **Best Technologies** Fortress LI 660 (2 Batteries Required) , **Best Technologies** Fortress LI 750 (BAT-0062) (2 Batteries Required) , **Best Technologies** Fortress Rack Mount LI 1050 (3 Batteries Required) , **Best Technologies** Fortress Rack Mount LI 1422 (4 Batteries Required) , **Best Technologies** Fortress Rack Mount LI 1425 (4 Batteries Required) , **Best Technologies** Fortress Rack Mount LI 750 (2 Batteries Required) , **Best Technologies** Fortress Rack Mount LI 750 (BAT-0062) (2 Batteries Required) , **Best Technologies** LCR12V6.5BP1 (1 Battery Required) , **Best Technologies** LI 520 BTG-0301 (2 Batteries Required) , **Best Technologies** LI660 (1 Battery Required) , **Best Technologies** LI660VA (1 Battery Required) , **Best Technologies** LI 720 BTG-0301 (2 Batteries Required) , **Best Technologies** MD1.5KVA (1 Battery Required) , **Best Technologies** MD2KVA (1 Battery Required) , **Best Technologies** PATRIOT 280 (1 Battery Required) , **Best Technologies** PATRIOT 600 (1 Battery Required) , **Best Technologies** SPS450 (1 Battery Required) , **Best Technologies** SPS450VA (1 Battery Required) , **Clary** 1000 On Guard (4 Batteries Required) , **Clary** 1800VA (1 Battery Required) , **Clary** I800VA (4 Batteries Required) , **Clary** UPS11251GR (1 Battery Required) , **Clary** UPS1125K1G (1 Battery Required) , **Clary** UPS1125K1GSBS (1 Battery Required) , **Clary** UPS1125K1GSBSR (1 Battery Required) , **Clary** UPS1-1.5K-1G (5 Batteries Required) , **Clary** UPS115K1GR (1 Battery Required) ,

ClaryUPS115K1GSBS (1 Battery Required) , **Clary** UPS115K1GSBSR (1 Battery Required) , **Clary** UPS11K1G (5 Batteries Required) , **Clary** UPS11K1GR (1 Battery Required) , **Clary** UPS11K1GSBSR (1 Battery Required) , **Clary** UPS1400VA1GSL (1 Battery Required) , **Clary** UPS1800VA1G (1 Battery Required) , **Clary** UPS1800VA1GR (1 Battery Required) , **Clary** UPS1800VA1GSBS (1 Battery Required) , **Clary** UPS1800VA1GSBSR (1 Battery Required) , **Clary** UPS23K1GSBSR (1 Battery Required) , **Clary** UPS800VA1GSBS (1 Battery Required) , **Compaq** R1500 (4 Batteries Required) , **Compaq** UP6003-2 (10 Batteries Required) , **Cyber Power** CPS1250AVR (2 Batteries Required) , **Cyber Power** CPS500SL (1 Battery Required) , **Cyber Power** CPS575SL (1 Battery Required) , **Cyber Power** CPS585AVR (1 Battery Required) , **Cyber Power** CPS625AVR (1 Battery Required) , **Cyber Power** CPS650SL (1 Battery Required) , **Cyber Power** CPS700AVR (1 Battery Required) , **Cyber Power** CPS900AVR (2 Batteries Required) , **Cyber Power** OFFICE POWER 1000AVR (2 Batteries Required) , **Cyber Power** OFFICE POWER 1500AVR (4 Batteries Required) , **Cyber Power** OFFICE POWER 900AVR (2 Batteries Required) , **Cyber Power** OFFICE POWER BA-825AVR (1 Battery Required) , **Data General** C4-775A (2 batteries Required) , **Data General** L600 (2 Batteries Required) , **Data Shield** ST 360 (1 Battery Required) , **Data Shield** T2+200 (2 Batteries Required) , **Deltec** PRA600 (2 Batteries Required) , **Deltech** PRA 400 (2 Batteries Required) , **Deltech** PRB220 (1 Battery Required) , **Deltech** PRB300 (1 Battery Required) , **Deltech** PRM450 (1 Battery Required) , **Deltech** RS-21 (10 Batteries Required) , **Deltech** RS-32 (10 Batteries Required) , **Easy Options** 400VA (1 Battery Required) , **Eaton** 3105-700 (1 Battery Required) , **Eaton** 9120-1000 (3 Batteries Required) , **Eaton** 9120-1500 (4 Batteries Required) , **Eaton** 9120-3000 (8 Batteries Required) , **Eaton** 9120-700 (1 Battery Required) , **EFI** LANGUARD 500 (2 Batteries Required) , **EFI** LANGUARD 600 (2 Batteries Required) , **EFI** LANGUARD 675 (1 Battery Required) , **Emerson** 200 (2 Batteries Required) , **Emerson** AU-750-60 (3 Batteries Required) , **EPD** Grizzly 300VRS (2 Batteries Required) , **EPD** Grizzly 500 (4 Batteries Required) , **EPD** Grizzly VRS500 (4 Batteries Required) , **EPE** INTEGRITY IS-1122/11 (6 Batteries Required) , **Fenex** FX2002 (2 Batteries Required) , **Fenton** M1000 (3 Batteries Required) , **Fenton** M2000 (6 Batteries Required) , **Fenton** M3000 (8 Batteries Required) , **Fenton** Power On H010K (1 Battery Required) , **Fenton** Power On H3500 (1 Battery Required) , **Fenton** Power On H4000 (1 Battery Required) , **Fenton** Power On H5500 (1 Battery Required) , **Fenton** Power On H6000 (1 Battery Required) , **Fenton** Power On H8000 (1 Battery Required) , **Fenton** Power Pal L425 (1 Battery Required) , **Fenton** Power Pure M1000 (1 Battery Required) , **Fenton** Power Pure M2000 (1 Battery Required) , **Fenton** PS60 (2 Batteries Required) , **General Power** GPS5006 (5 Batteries Required) , **Hewlett Packard** HP 1000 (2 Batteries Required) , **Hewlett Packard** PowerWise 1000 (4 Batteries Required) , **Hewlett Packard** PowerWise 1250 (4 Batteries Required) , **Hewlett Packard** PowerWise 2100 (1 Battery Required) , **Hewlett Packard** Powerwise L600 (2 Batteries Required) , **Hewlett Packard** PowerWise L900 (2 Batteries Required) , **Intellipower** IQ 1100RM (3 Batteries Required) , **Leadman** UPS (1 Battery Required) , **Leadman** UPS 300 (2 Batteries Required) , **Leadman** UPS 500 (2 Batteries Required) , **Liebert** GXT2-2000RT230 (4 Batteries Required) , **Liebert** GXT2-3KRT230E (6 Batteries Required) , **Liebert** PowerSure Interactive PS 1000MT (3 Batteries Required) , **Liebert** PowerSure Interactive PS1000RM (3 Batteries Required) , **Liebert** PowerSure Interactive PS 1400MT (4 Batteries Required) , **Liebert** PowerSure Interactive PS 1400RM (4 Batteries Required) , **Liebert** PowerSure Interactive PS 700MT (2 Batteries Required) , **Liebert** PowerSure Interactive PS 700RM (2 Batteries Required) , **Liebert** PowerSure Personal PSP 500 (1 Battery Required) , **Liebert** PowerSure Proactive PSA 350 (1 Battery Required) , **Liebert** PowerSure Proactive PSA 470 (1 Battery Required) , **Liebert** Up Station D 600VA (2 Batteries Required) , **Liebert** Up Station D PSP 500 (1 Battery Required) , **Liebert** Up Station D S1000MT (3 Batteries Required) , **Liebert** Up Station D S1400MT (4 Batteries Required) , **Liebert** Up Station GXT 1000MT-120 (3 Batteries Required) , **Liebert** Up Station GXT 1000RT-120 (3 Batteries Required) , **Liebert** Up Station GXT 1000RTE-120 (6 Batteries Required) , **Liebert** Up Station GXT 1500RT-120 (4 Batteries Required) , **Liebert** Up Station GXT 2000RT-120 (8 Batteries Required) , **Liebert** Up Station GXT 2100RT-60 (8 Batteries Required) , **Liebert** Up Station GXT 3000RT-120 (8 Batteries Required) , **Liebert** Up Station GXT 00MT-120 (2 Batteries Required) , **Merich** 350 (2 Batteries Required) , **Merich** 400 (2 Batteries Required) , **Merich** 450C (4 Batteries Required) , **Merich** 850C (4 Batteries Required) , **Merich** M1200 (6 Batteries Required) , **Merich** UPS400 (2 Batteries Required) , **MGE** Ellipse 1000 USBS (2 Batteries Required) , **MGE** Ellipse ASR 1000 (2 Batteries

Required), **MGE** Ellipse ASR 1500 (3 Batteries Required), **MGE** Ellipse ASR 375 (1 Battery Required), **MGE** Ellipse ASR 600 (1 Battery Required), **MGE** Ellipse ASR 750 (1 Battery Required), **MGE** ES8+ (2 Batteries Required), **MGE** ESV11 (3 Batteries Required), **MGE** ESV13+ (4 Batteries Required), **MGE** ESV14+ (4 Batteries Required), **MGE** ESV8 (2 Batteries Required), **MGE** Evolution 1100 (2 Batteries Required), **MGE** Evolution 1500 (3 Batteries Required), **MGE** Evolution 2200 (6 Batteries Required), **MGE** Evolution 3000 (6 Batteries Required), **MGE** Evolution 800 (2 Batteries Required), **MGE** Pulsar EL7 (2 Batteries Required), **MGE** Pulsar ESV11 (3 Batteries Required), **MGE** Pulsar ESV14 (4 Batteries Required), **MGE** Pulsar Evolution 1100 (2 batteries required), **MGE** Pulsar Evolution 1100VA Tower (1 battery required), **MGE** Pulsar Evolution 1500 (3 batteries required), **MGE** Pulsar Evolution 2200 (6 batteries required), **MGE** Pulsar Evolution 3000 (6 batteries required), **MGE** Pulsar Evolution 800 (2 batteries required), **MGE** Pulsar Evolution 800VA Tower (1 battery required), **MGE** Pulsar Evolution EVS8 (2 batteries required), **NCR** UPS 4071-0600-7194 (2 Batteries Required), **Oneac** 436-008 (4 Batteries Required), **Oneac** 436-014 (4 Batteries Required), **Oneac** ON1300 (6 Batteries Required), **Oneac** ON2000 (8 Batteries Required), **Oneac** ON400XR (2 Batteries Required), **Oneac** ON600 (2 Batteries Required), **Oneac** ONE200 (1 Battery Required), **Oneac** ONE200X (2 Batteries Required), **Oneac** ONE300 (1 Battery Required), **Oneac** ONE300X (2 Batteries Required), **Oneac** ONE400D (2 Batteries Required), **Oneac** ONm300 (1 Battery Required), **Oneac** ONm600X (2 Batteries Required), **Oneac** Series E ON1300 (6 Batteries Required), **Oneac** Series E ON2000 (8 Batteries Required), **Oneac** Series E ON900 (4 Batteries Required), **Oneac** Series E ONE300D (2 Batteries Required), **Oneac** Series E ONE400D (2 Batteries Required), **Oneac** UP-1105 (4 Batteries Required), **Opti** 1300 (1 Battery Required), **Opti** 1BP107 (1 Battery Required), **Opti** 1BP207 (1 Battery Required), **Opti** 1BP407 (1 Battery Required), **Opti** 1BP607 (1 Battery Required), **Opti** 2000 (1 Battery Required), **Opti** 280E (1 Battery Required), **Opti** 280 ES (1 Battery Required), **Opti** 350059 (1 Battery Required), **Opti** 350VS (1 Battery Required), **Opti** 400XR (1 Battery Required), **Opti** 420E (1 Battery Required), **Opti** 500VS (1 Battery Required), **Opti** 600 (1 Battery Required), **Opti** 800PS (2 Batteries Required), **Opti** 900 (1 Battery Required), **Opti** BT (1 Battery Required), **Opti** BT2PAC (1 Battery Required), **Opti** BT4PAC (1 Battery Required), **Opti** ON1300 (1 Battery Required), **Opti** ON1300XRA (1 Battery Required), **Opti** ON2000 (1 Battery Required), **Opti** ON2000XRA (1 Battery Required), **Opti** ON400XR (1 Battery Required), **Opti** ON400XRA (1 Battery Required), **Opti** ON600 (1 Battery Required), **Opti** ON600XRA (1 Battery Required), **Opti** ON900 (1 Battery Required), **Opti** ON900XRA (1 Battery Required), **Opti** ON910 (1 Battery Required), **Opti** ONEBP107 (1 Battery Required), **Opti** ONEBP207 (1 Battery Required), **Opti** ONEBP407 (1 Battery Required), **Opti** ONEBP607 (1 Battery Required), **Opti** UP1103 (1 Battery Required), **Parasystems** MINUTEMAN A300 (1 Battery Required), **Parasystems** MINUTEMAN A300/2 (1 Battery Required), **Parasystems** MINUTEMAN A300L (1 Battery Required), **Parasystems** MINUTEMAN A425 (1 Battery Required), **Parasystems** MINUTEMAN A425/2 (1 Battery Required), **Parasystems** MINUTEMAN A750/2 (2 Batteries Required), **Parasystems** MINUTEMAN A750 (2 Batteries Required), **Parasystems** MINUTEMAN Rack Mount PRO 1000R (4 Batteries Required), **Parasystems** MINUTEMAN Rack Mount PRO 1400R (4 Batteries Required), **Parasystems** MINUTEMAN Rack Mount PRO 700R (2 Batteries Required), **Para Systems** A750 (2 Batteries Required), **Para Systems** MINUTEMAN 1000 (7 Batteries Required), **Para Systems** MINUTEMAN 250 (1 Battery Required), **Para Systems** MINUTEMAN 300CP (16 Batteries Required), **Para Systems** MINUTEMAN 300SS (2 Batteries Required), **Para Systems** MINUTEMAN 450 (1 Battery Required), **Para Systems** MINUTEMAN 600 (1 Battery Required), **Para Systems** MINUTEMAN 60022 (4 Batteries Required), **Para Systems** MINUTEMAN 600SS (4 Batteries Required), **Para Systems** MINUTEMAN 900SS (8 Batteries Required), **Para Systems** MINUTEMAN AT650 (1 Battery Required), **PCM** Powercom KIN-1000AP (2 Batteries Required), **PCM** Powercom KIN-625AP (1 Battery Required), **Powerware** 5155 (2 Batteries Required), **Powerware** EMB9120-1500 (8 Batteries Required), **Powerware** EMB9120-2000 (16 Batteries Required), **Powerware** FX2002 (2 Batteries Required), **Powerware** PLUS 6 (20 Batteries Required), **Powerware** Powerware OneUPS (1 Battery Required), **Powerware** Powerware PW3110-250 (1 Battery Required), **Powerware** Powerware PW3110-425 (1 Battery Required), **Powerware** Powerware PW3115-300 (1 Battery Required), **Powerware** Powerware PW5105-450 (1 Battery Required), **Powerware** Powerware PW5115-750 (2 Batteries Required), **Powerware** Powerware PW5119-1500 (3 Batteries Required),

Powerware Powerware PW9120-1000 (3 Batteries Required) , **Powerware** Powerware PW9120-1500 (4 Batteries Required) , **Powerware** Powerware PW9120-2000 (8 Batteries Required) , **Powerware** Powerware PW9120-3000 (8 Batteries Required) , **Powerware** Powerware PW9120-700 (2 Batteries Required) , **Powerware** Powerware PW9130-2000 (6 Batteries Required) , **Powerware** Powerware PW9130-3000 (6 Batteries Required) , **Powerware/Exide** Exide PW 3115-300 (1 Battery Required) , **Powerware/Exide** Exide PW 5105-450 (1 Battery Required) , **Safe** 650 (2 Batteries Required) , **Safe** SM650 (2 Batteries Required) , **Scooter** SPS500AT (6 Batteries Required) , **Sola** 0510-0900U (4 Batteries Required) , **Sola** 054-00210-0100-19 (600VA) (4 Batteries Required) , **Sola** 2993638601 (1 Battery Required) , **Sola** 305 (1 Battery Required) , **Sola** 310A (1 Battery Required) , **Sola** 600VA (4 Batteries Required) , **Sola** 900VA (1 Battery Required) , **Sola** N900 (2 Batteries Required) , **Sola** NETWORK UPS N900 (4 Batteries Required) , **Sola** S24K2U48BAT (8 Batteries Required) , **Sola** S31000 (3 Batteries Required) , **Sola** S31000R (3 Batteries Required) , **Sola** S314000 (4 Batteries Required) , **Sola** S31400R (4 Batteries Required) , **Sola** S32200R (8 Batteries Required) , **Sola** S3700 (2 Batteries Required) , **Sola** S3700R (2 Batteries Required) , **Sola** S370 (2 Batteries Required) , **Sola** S41000 (3 Batteries Required) , **Sola** S41000TRM (3 Batteries Required) , **Sola** S41500TRM (4 Batteries Required) , **Sola** S4700 (2 Batteries Required) , **Sola** S4K2U2000 (4 Batteries Required) , **Toshiba** 1200 3 KVA (1 Battery Required) , **Toshiba** 1200 5KVA (1 Battery Required) , **Toshiba** 1200 Model 3 (1 Battery Required) , **Toshiba** 1200 SER .5KVA (1 Battery Required) , **Toshiba** 1400SE Plus (8 Batteries Required) , **Toshiba** 5KVA 208 Vol (1 Battery Required) , **Toshiba** 5KVA 240 Volt (1 Battery Required) , **Toshiba** 750 (1 Battery Required) , **Toshiba** ECB1U12030U (1 Battery Required) , **Toshiba** PR00015P31 (1 Battery Required) , **Triad** UPS600 (6 Batteries Required) , **Tripp Lite** 360SX (2 Batteries Required) , **Tripp Lite** 500 (1 Battery Required) , **Tripp Lite** 600 (3 Batteries Required) , **Tripp Lite** 850 (4 Batteries Required) , **Tripp Lite** BC200-228B (1 Battery Required) , **Tripp Lite** BC250 (1 Battery Required) , **Tripp Lite** BC250A (3 Batteries Required) , **Tripp Lite** BC300 Internet (2 Batteries Required) , **Tripp Lite** BC325 (2 Batteries Required) , **Tripp Lite** BC325A (2 Batteries Required) , **Tripp Lite** BC3348 (1 Battery Required) , **Tripp Lite** BC400INT (1 Battery Required) , **Tripp Lite** BC400 LAN (3 Batteries Required) , **Tripp Lite** BC400 Standby (1 Battery Required) , **Tripp Lite** BC 420 (1 Battery Required) , **Tripp Lite** BC420 (1 Battery Required) , **Tripp Lite** BC450 (1 Battery Required) , **Tripp Lite** BC 500 (1 Battery Required) , **Tripp Lite** BC500LAN (1 Battery Required) , **Tripp Lite** BC Internet 450 (1 Battery Required) , **Tripp Lite** BC Internet 500 (1 Battery Required) , **Tripp Lite** BC Internet 550 (1 Battery Required) , **Tripp Lite** BC PERS 420 (1 Battery Required) , **Tripp Lite** BC PERS 450 (1 Battery Required) , **Tripp Lite** BC Personal 420 (1 Battery Required) , **Tripp Lite** BC PRO 450 (1 Battery Required) , **Tripp Lite** BC PRO600 (1 Battery Required) , **Tripp Lite** BC PRO 850A (3 Batteries Required) , **Tripp Lite** CP 350 (2 Batteries Required) , **Tripp Lite** Datashield PC200A (2 Batteries Required) , **Tripp Lite** Datashield T2+200 (2 Batteries Required) , **Tripp Lite** Datashield T2+300 (2 Batteries Required) , **Tripp Lite** Internet Office 500 (1 Battery Required) , **Tripp Lite** MISC TMC CP350 (3 Batteries Required) , **Tripp Lite** MPS 1500 (6 Batteries Required) , **Tripp Lite** Office 500 (1 Battery Required) , **Tripp Lite** OM1995 (1 Battery Required) , **Tripp Lite** OMNI 2000A (6 Batteries Required) , **Tripp Lite** OMNI 600B LAN (2 Batteries Required) , **Tripp Lite** OMNI 850 (4 Batteries Required) , **Tripp Lite** OMNI PRO Network Pro 450 (1 Battery Required) , **Tripp Lite** OMNI SMART 450 (1 Battery Required) , **Tripp Lite** PS6.0 (2 Batteries Required) , **Tripp Lite** SMART 400 UPS(1 Battery Required) , **Tripp Lite** SMART 450 (1 Battery Required) , **Tripp Lite** SMART PRO Net 450 (1 Battery Required) , **Tripp Lite** SMART Unison PS700 (2 Batteries Required) , **Tripp Lite** TE1200 (1 Battery Required) , **Tripp Lite** TE700 (1 Battery Required) , **Tripp Lite** Unison MPS1200 (5 Batteries Required) , **Tripp Lite** Unison MPS1200A (4 Batteries Required) , **Tripp Lite** Unison PS6.0 (2 Batteries Required) , **Tripp Lite** Unison PS6.0N (2 Batteries Required) , **Tripp Lite** Unison PS8.0 (2 Batteries Required) , **Unison** MPS1200 (5 Batteries Required) , **Unison** MPS1200A (4 Batteries Required) , **Unison** MPS1500 (6 Batteries Required) , **Unison** PS60 (2 Batteries Required) , **Unison** PS6 (2 Batteries Required) , **Unisys** MPS1400 (4 Batteries Required) , **Unisys** MPS2000 (8 Batteries Required) , **Unisys** PS60 (2 Batteries Required) , **Unisys** PS6.0 N (2 Batteries Required) , **Unisys** PS700 (2 Batteries Required) , **Unisys** PS8.0 (2 Batteries Required) , **Unisys** PS8.0 N (2 Batteries Required) , **Upsonic** CS 1500 (2 batteries required) , **Upsonic** CS 3000 (4 batteries required) , **Upsonic** CXR 1500 (4 batteries required) , **Upsonic** CXR 3000 (8 batteries required) , **Upsonic** DS 1400 (2 Batteries Required) ,

UpsonicDS 2000 (2 Batteries Required) , **Upsonic** DS 800 (1 Battery Required) , **Upsonic** ESLR 15 (16 batteries required) , **Upsonic** ESLR 20 (16 batteries required) , **Upsonic** ESLR 30 (16 batteries required) , **Upsonic** ESLR 50 (16 batteries required) , **Upsonic** ESLR 75 (16 batteries required) , **Upsonic** ESRT 20 (3 batteries required) , **Upsonic** ESRT 50 (8 batteries required) , **Upsonic** EST 20 (3 batteries required) , **Upsonic** IP 10000 (20 batteries required) , **Upsonic** IS 2000 (6 batteries required) , **Upsonic** IS 3000 (8 batteries required) , **Upsonic** LAN 100 (4 Batteries Required) , **Upsonic** LAN 150 (6 Batteries Required) , **Upsonic** Might 35 (1 Battery Required) , **Upsonic** Orion 750 (1 Battery Required) , **Upsonic** PCM 140 (2 Batteries Required) , **Upsonic** PCM 140VR (2 Batteries Required) , **Upsonic** PCM 200 (2 Batteries Required) , **Upsonic** PCM 200VR (2 Batteries Required) , **Upsonic** PCM 35 (2 Batteries Required) , **Upsonic** PCM 55 (2 Batteries Required) , **Upsonic** PCM 55R (2 Batteries Required) , **Upsonic** PC Mate 55 (2 Batteries Required) , **Upsonic** PC Might 35 (1 Battery Required) , **Upsonic** PC Might 55 (2 Batteries Required) , **Upsonic** Station 140 (4 Batteries Required) , **Upsonic** Station 200 (2 Batteries Required) , **Upsonic** Station 28 (1 Battery Required) , **Upsonic** Station 40 (2 Batteries required) , **Upsonic** Station 60 (2 Batteries Required) , **Upsonic** System 100 (2 Batteries Required) , **Upsonic** System 300 (2 Batteries Required) , **Upsonic** System 60 (2 Batteries Required) , **Upsonic** UPS 1250 (2 Batteries Required) , **Upsonic** UPS 200 (2 Batteries Required) , **Upsonic** UPS 600 (2 Batteries Required) , **Zapotek** RX501N (1 Battery Required) , **Zapotek** RX-501N (4 Batteries Required) , **Zapotek** RX510N (4 Batteries Required) , **Zapotek** RX510N (Sota SA1272F003) (1 Battery Required) , **Zapotek** SA1272f003 (1 Battery Required)

Zastępuje akumulatory o nr / typ / cecha :

HR1234W F2; HR-1234W F2; HR 1234W F2; EP1234W;CPSBK2 Enersys / Yuasa SW200 Panasonic UP-RWA1245P1 / UP-RW1245P1 Panasonic LC-R129CH1 / LC-R129P1 UP-VW1245P1 / UP-VW1234P1 GS Portalac PX12090 TPH12100 Yuasa NP7-12 / SW200 / REW45-12 FR DaiMec DMU12-8 BB Battery HR8-12 / HR9-12;RBC2

Używany w :

APC BackUPS BK1200; APC BackUPS BK650S; APC BackUPS BR1000; APC BackUPS BX800; APC BackUPS BX1000; APC BackUPS BX1200; UPS Powercom BNT-800AP

Zastosowania:

Praca buforowa
UPS
Sprzęt medyczny
Telekomunikacja
Automatyka
Oświetlenie awaryjne
Systemy nadzoru
Telefonia komórkowa
Ochrona katodowa
Pomoce nawigacyjne
Sprzęt okrętowy
Systemy zasilania

Wymiary:151x65x94 mm. Waga 2,62 kg

[Karta katalogowa akumulatora HR 1234WF2 CSB 9.0Ah 12.0V](#)

Zapytaj o alternatywne wykonanie tego produktu

Złóż zapytanie mailem biuro@baterie-a.pl

Seria HR to nowoczesne akumulatory bezobsługowe zaprojektowane do pracy buforowej o standardowej żywotności i niewielkich wymiarach. Produkowane zgodnie z wymaganiami bezpieczeństwa, jakości oraz ochrony środowiska. Główne cechy:

- * powyżej 260 cykli ładowania / 100% rozładowania w pracy cyklicznej
- * 3-5 lat projektowana żywotność (w 25C) w pracy buforowej
- * niewielkie wymiary
- * niewielka waga

* wysoka wydajność prądowa
